



**Ford Crown Victoria/Excursion
Mirror Mount Grommet:**



#PPRDDMMFPI (pair)

**Ford Crown Victoria
Mirror Mount Grommet:**



#PPRDSMMFPI (pair)

**Dodge Charger
Mirror Mount Grommet:**



#PPRDSMMFDC (pair)

**Honda ST 1300P
Mirror Housing Brackets:**



#PRDSMMHBM (pair)

**Honda & Kawasaki
Crash Bar Brackets:**



#PRDSMMSBM (pair)
1" diameter

**Harley Davidson
Crash Bar Brackets:**



#PRDSMMLBM (pair)
1.25" diameter

45° Brackets:

Vertical (kit shown)



Horizontal (shown w/ light)



90° Bracket:



(kit shown)

**License Plate
Dual Side-by-Side Bracket:**



#PPDSMLBKCV (each)

Vertical #PPRSM45BRKT (pair)
Horizontal #PPRSM45HBRKT (pair)

#PPRSM90BRKT (pair)